



Wired Earphones USB-C™

Instrukcja obsługi

PL

Wskazówki dotyczące użytkowania

- Nie zostawiaj słuchawek w kieszeni podczas prania ubrań.
- Wyjmij słuchawki i włóż je do uszu, lekko nimi poruszaj, aby uzyskać najlepsze dopasowanie i komfort.
- Słuchawki powinny być przechowywane w suchym/ wentylowanym miejscu i należy unikać kontaktu z olejem, parą wodną, wilgocią i kurzem, aby nie pogorszyć działania produktu.
- Do czyszczenia słuchawek należy unikać używania ostrych rozpuszczalników organicznych lub przedmiotów zawierających te składniki.

Dane techniczne produktu

- Nazwa: 3mk WiredEarphones
- Wyjście: USB-C
- Rozmiar głośnika: 10mm
- Impedancja: 16 Ω
- Wrażliwość: 93dB \pm 3dB
- Wrażliwość mikrofonu: 40dB \pm 3 dB
- Zakres częstotliwości: 20 – 20000 Hz
- Długość kabla: 1,2 m

Funkcje słuchawek

- Jedno kliknięcie
- Dwa kliknięcia
- Trzy kliknięcia



- Zwiększanie głośności
- Odbieranie/Kończenie | odtwarzanie/ pauza
- Następnny utwór
- Poprzedni utwór
- Redukowanie głośności

Informacje dotyczące bezpieczeństwa

Przed rozpoczęciem użytkowania i korzystania ze słuchawek przeczytaj poniższe wskazówki, aby jak najlepiej wykorzystać ich możliwości i uniknąć sytuacji niebezpiecznych lub niezgodnych z prawem.

Utrata słuchu

- Słuchanie dźwięku o dużej głośności może trwale uszkodzić słuch. W przypadku korzystania ze słuchawek do słuchania muzyki lub prowadzenia rozmów, zaleca się używanie minimalnej głośności wymaganej dla muzyki lub rozmów, aby uniknąć uszkodzenia słuchu.
- Ekspozycja na głośne dźwięki podczas prowadzenia samochodu powoduje, że uwaga kierowcy może być rozproszona i może dojść do wypadku.

Zdrowie dzieci

- Urządzenie i jego akcesoria mogą składać się z małych części. Urządzenie i jego akcesoria należy przechowywać w miejscu niedostępnym dla dzieci. Dzieci mogą nieumyślnie uszkodzić urządzenie i jego akcesoria lub połknąć małe części, co może spowodować uduszenie lub inne zagrożenia.
- Urządzenie nie jest zabawką, dzieci powinny używać go pod nadzorem dorosłych.

Środki ostrożności



Symbol na produkcie, baterii, dokumentacji lub o opakowaniu oznacza, że po zakończeniu okresu eksploatacji produkty i baterie należy oddać do selektywnych punktów zbiórki odpadów wyznaczonych przez władze lokalne. Dzięki temu odpady WEEE będą poddawane recyklingowi i przetwarzane w sposób, który chroni środowisko.





Wired Earphones USB-C™

User manual

EN

Usage tips

- Don't leave your earphones in your pocket when washing clothes.
- Remove the earphones and place them in your ears, wiggle them slightly for the best fit and comfort.
- The earphones should be stored in a dry/ventilated place and any contact with oil, steam, moisture and dust should be avoided not to affect the performance of the product.
- Avoid using harsh organic solvents or items containing these ingredients to clean the earphones.

Product specification

- Name: 3mk WiredEarphones
- Plug: USB-C
- Speaker size: 10mm
- Impedance: 16 Ω
- Sensivity: 93dB ± 3dB
- Microphone sensitivity: 40dB ± 3 dB
- Frequency range: 20 – 20000 Hz
- Wire length: 1,2 m

Earphones function

- Single press
- Double press
- Triple press



- Increase the volume
- Answer/end | Play/pause
- Next song
- Previous song
- Reduce the volume

Safety information

Before using and operating the earphones, please read and follow the precautions below to ensure optimum use and safety.

Hearing loss

- Listening sounds at a high volume may permanently damage your hearing. When you use earphones to listen to music or take calls, it is recommended to use the minimum volume required for music or calls to avoid damaging your hearing.
- Using when driving may impair your concentration and cause you to be distracted which may cause a car accident.

Child health

- This device and its accessories may contain some small parts. Keep the device and its accessories out of reach of children. Children may inadvertently damage the device and its accessories, or swallow small parts, causing suffocation or other hazards.
• This device is not a toy, children should use this device under adult supervision

Precautions



The symbol on the product, battery, documentation or packaging indicates that at the end of their service life, products and batteries should be disposed of at selective waste collection points designated by local authorities. This will ensure that WEEE waste is recycled and treated in a way that protects the environment.

