





Electrolux

User Manual

**Ultimate 800
Wet & Dry
Cordless cleaner**




*Actual product may differ from illustration.





Accessories





KSA-30C-260110HE




Additional Parts



*Actual product may differ from illustration.



*Actual product may differ from illustration.




⌚ ≤4h 100%

■ 66-100%




■ 33-66%




■ 10-33%






■ 0-10%













Allow to use the hard floor detergent with low bubbles & pH value 5-8










 www.electrolux.com



EF162
900 923 594
Fine Dust Filter

*Availability of item varies by region and country.

